

2004-Current Yamaha Raptor 350

Jetting recommendations

- ❑ To access the carburetor, take the seat and fuel tank off.
- ❑ Be sure to turn the fuel petcock off before taking the tank off.
- ❑ Take the carburetor off of the motor and pull it up into the open.
- ❑ These recommendations are with the Sparks Exhaust, the Air box lid off, at sea level only. If you're using this kit to tune for another manufacturer's performance products, please contact that manufacturer for additional jetting recommendations.

	Main jet	Needle jet / clip position	Pilot (slow jet)	Fuel screw (from closed)
Raptor 350	134	Dynojet / 3rd	Stock	3 +/- .5

- ❑ Reinstall the carburetor making certain that everything is together correctly and tight.